

# Tech Bulletin

## Hose / Cord Replacement and Required Wraps

---

### Series RT

#### Replacing the Hose

To remove the hose - Pull out the hose leaving 2 to 3 feet on the spool. Engage the latch pawl. Remove the U-bolt nuts and washers on the inside of the spool. Remove the U-bolt. Un-thread the hose at the connection to the swivel tube. Use a wrench on both fittings or the swivel may be damaged. Remove the hose.

To install the hose - Route the hose through the guide arm rollers and opening of the spool. Apply thread tape or sealant to hose threads. Screw hose fitting into threaded fitting on swivel. Tighten connection with a wrench on both fittings. Install the U-bolt. Install hose bumper on working end of hose if required. Disengage latch pawl and allow hose to retract.

Reel w/hose	Reel w/o hose	Hose I.D.		Hose Length		# Wraps
RT425-OLP	RT402-OLP	1/4"	6mm	25'	8m	15
RT435-OLP	RT403-OLP	1/4"	6mm	35'	11m	15
RT450-OLP	RT405-OLP	1/4"	6mm	50'	15m	22
RT465-OLP	RT406-OLP	1/4"	6mm	65'	20m	26
RT625-OLP	RT602-OLP	3/8"	10mm	25'	8m	15
RT635-OLP	RT603-OLP	3/8"	10mm	35'	11m	15
RT650-OLP	RT605-OLP	3/8"	10mm	50'	15m	20
RT825-OLP	RT802-OLP	1/2"	13mm	25'	8m	15
RT835-OLP	RT803-OLP	1/2"	13mm	35'	11m	15
RT850-OLP	RT805-OLP	1/2"	13mm	50'	15m	21
RT625-OMP	RT602-OMP	3/8"	10mm	25'	8m	15
RT635-OMP	RT603-OMP	3/8"	10mm	35'	11m	15
RT650-OMP	RT605-OMP	3/8"	10mm	50'	15m	15
RT825-OMP	RT802-OMP	1/2"	13mm	25'	8m	15
RT835-OMP	RT803-OMP	1/2"	13mm	35'	11m	15
RT425-OHP	RT402-OHP	1/4"	6mm	25'	8m	15
RT435-OHP	RT403-OHP	1/4"	6mm	35'	11m	15
RT625-OHP	RT602-OHP	3/8"	10mm	25'	8m	15
RT635-OHP	RT603-OHP	3/8"	10mm	35'	11m	15
RT650-OHP	RT605-OHP	3/8"	10mm	50'	15m	21

Form # TB0020 Rev: 5/2012